

POWER SUPPLY (MAINS) AND BATTERY CHARGE (CHRG) LED STATUS



INSTRUMENT	CONNECTED TO THE MAINS POWER SUPPLY	▼ LED MAINS	▼ LED BATT CHRG	NOTES
OFF	NO	OFF	OFF	Batteries sufficiently charged
ON	NO	OFF	OFF	Battery operation
OFF	NO	OFF	Flashing 2 SECONDS OFF 0.5 SECONDS ON	The meter does not turn on. Recharge the batteries.
OFF	YES	ON	Flashing 0.5 SECONDS OFF 0.5 SECONDS ON	Abnormal battery temperature. The recharge cycle has been suspended temporarily and will automatically reset.
OFF	YES	ON	ON	Batteries in fast charge
OFF	YES	ON	OFF	Battery charge completed
OFF	WITH A POWER SUPPLY NOT FROM ROVER	Flashing 0.5 SECONDS OFF 0.5 SECONDS ON	OFF	The meter does not turn on. Check the mains power adapter, it must be 12 Vdc and not 18 Vdc
turning ON	Indifferent	FLASHES 15 TIMES	OFF	The meter is being turned on
ON	Indifferent	FLASHING SIMULTANEOUSLY 0.5 SECONDS OFF - 0.5 SECONDS ON		The meter detects an error and turns off automatically.
ON	YES	FLASHING ALTERNATIVELY 1 SECOND OFF - 1 SECOND ON		BATTERY TEST being carried out. The meter charges and discharges the batteries AUTOMATICALLY