




IMPORTANT:

Battery charge status



For safety and transportation reasons, the instrument is supplied with the Batteries partially discharged.

You must make a full battery charge before using the instrument.



Charging and storage

Charge the batteries every night.

Store the instrument in an environment with a temperature between 10 and 50° C.

During cold months store the instrument in heated rooms.

Operating range

***Ideal:* +10/+50°C**

The use of the instrument, outside the ideal temperature range, considerably modifies the performance of the batteries.